

1. For Solid wire, peeling wire in right length, push down spring to claptthe wire.
2. For stranded wire, connect directly after peeling in right length, or wire furrled and fix in by pushingthe spring.

订货号 Order No.	2569XX		名 称 Name	2569XX 系列PCB 电路板用 组合端子排	未注公差 Tolerance	表面 Surface		
项 目 Item	签 字 Signature	日 期 Date			Tolerances Table	VDI21		
设 计 Design	JCY	2024.05.23	图 号 Drawing No.	PRM000766	版本号 Revision Number	重量 Weight	比例 Scale	
审 核 Check	BYH	2024.05.23	材 料 Material	Notes	MO	/	1:1	
工 艺 Process	-	-	物料号 Item No.	/	第1页/共1页 1 of 1	 mm		
标准化 Unify	-	-		...	SUPU 宁波盛普电子有限公司 NINGBO SUPU ELECTRONICS CO.,LTD.			
批 准 Approve	XJ	2024.05.23		/				